

ELD INSTALLATION AND SETUP GUIDE

Installation Steps:

1. Turn Off the Engine

Ensure the engine is turned off before beginning installation to prevent damage to the device.

2. Locate the Diagnostic Port (OBD-II)

Find the OBD-II port under the dashboard near the driver's seat or steering wheel. Refer to your vehicle's manual if needed.

3. Connect the ELD

Securely plug the ELD device into the diagnostic port and twist the lock until it clicks.

4. Sync with Engine Control Module (ECM)

The ELD will automatically sync with the ECM. Wait a minute for the connection to establish.

5. Launch the DriverBook Application

Locate the DriverBook app icon on your tablet or mobile device's home screen, then tap it to open the application.

6. Log into DriverBook

Use your username and password to log in. Contact your fleet manager if you don't have login credentials.

7. Connect the My Driver Book App to the ELD


The app will detect available ELD devices. Select your device and ensure a green icon appears to confirm a successful connection.

8. Verify Functionality

Double-check the connection and confirm the ELD is functioning properly.

Important:


For your safety, do not call for support while driving. Only seek assistance when your vehicle is stationary and the engine is off.



Once connected, real-time vehicle data, such as speed, will be displayed.
(When driving over 5 MPH, the app will automatically switch to the Driving screen.)

Note:

Blinking blue = Device initializing.
Solid blue = Device operational (refer to manual for variations).



Note:

Download the app from App Store iOS or Play Store Android.

Reminder:

Keep this guide in your vehicle for FMCSA compliance.

Need Help?

+1 909-255-9252 ■ support@mydriverbook.com